

## How to Use a Power Paddle

### Introduction

The power paddle provides a temporary power source to the NXT and NXT Wireless (blue) series lockboxes. If the internal batteries in the lockbox are dead, you will need a temporary power source to allow you to open the key compartment and replace the internal lockbox batteries.

*Note:* It is important to read through these directions before you use the power paddle at a lockbox.

To determine if the lockbox batteries are dead, insert your SentiCard® into the lockbox and press the lockbox keypad buttons. If the lights on the lockbox do not illuminate and the lockbox does not make any sounds, the batteries are dead.

*Note:* Before the lockbox batteries die, the lockbox will alert you. When you insert your SentiCard® into the lockbox, followed by entering your PIN, the lockbox will illuminate the **MESSAGE** light. The **MESSAGE** light indicates it is time to replace the lockbox batteries. Once the **MESSAGE** light illuminates, you will have a couple of weeks (depending upon lockbox usage) to replace the lockbox batteries. When the **MESSAGE** light illuminates SentiLock recommends replacing the lockbox batteries as soon as possible.



### Before Using the Power Paddle at a Lockbox

Before you can use the power paddle at a lockbox, you need a time stamp file on your SentiCard®. This allows the power paddle to set the internal lockbox clock, while providing temporary power to the lockbox. You need to contact SentiLock Support for a time stamp file. Before you contact SentiLock Support, you need:

1. The serial number of the lockbox.
2. A computer with a SentiCard® reader and an active Internet connection.

When you are ready, you can reach SentiLock Support at 877-736-8745.

Before you can use the power paddle at the lockbox, it is important to make sure the power paddle is working properly. To do this, follow these steps:

1. Slide the **POWER** switch to the **ON** position.
2. The green **POWER** light should illuminate. If this light does not illuminate, replace the 9 volt battery in the power paddle.

*Note:* The battery compartment is located on the back of the power paddle.



Before using the power paddle at a lockbox, make sure you have the following items:

- The power paddle
- Your valid SentiCard® (SentiCard® cannot be expired)
- 2, new CR123A batteries
- A Phillips head screw driver
- These instructions on how to use the power paddle
- Instructions on how to replace the batteries in an NXT/NXT Wireless lockbox (these instructions can be found at <https://lockbox.sentrilock.com/manuals/faq/default.htm> in the topic entitled *Replace the Battery in an NXT/NXT Wireless (Blue) Lockbox* within the *Using Your Lockbox* section)

### How to Use the Power Paddle

Listed below are the steps to use the power paddle at a lockbox:

1. Insert the power paddle into the lockbox card slot.

*Note:* Do not remove the power paddle from the lockbox. It must remain inserted into the lockbox card slot until the end of the procedure.



2. Slide the **Power** switch on the power paddle to the **ON** position. The green **POWER** light will illuminate.

*Note:* If the green **POWER** light does not illuminate, you may need to replace the 9 volt battery inside the power paddle. The battery compartment is located on the back of the power paddle.



3. Once the power paddle is turned on, the red **Status A** light will illuminate for approximately one minute. During this time, the power paddle is charging the lockbox.
4. When the power paddle finishes charging the lockbox, the yellow **Status B** light will illuminate.

5. Once the yellow **Status B** light has illuminated, insert your SentiCard® into the card slot on the left side of the power paddle. The SentiCard® must be inserted face up with the gold chip going in first.



Phone: 877-736-8745 • Fax: 513-618-5801

[www.sentrilock.com](http://www.sentrilock.com)

2710 East Kemper Road • Cincinnati OH 45241



The steps to use the power paddle at an NXT series lockbox and an NXT Wireless series lockbox are different. Please follow the steps according to which lockbox you are using the power paddle on. To determine what type of NXT lockbox you are using the power paddle on, refer to the front, left side of the lockbox. If you find a *Wireless* sticker here, you are using an NXT Wireless lockbox. If the sticker is not there, you are not using an NXT Wireless lockbox.

#### **NXT Lockbox:**

6. The lockbox will illuminate the **CARD** and **CODE** lights.
7. Wait for the green **Status C** light to illuminate on the power paddle.
8. Enter your **PIN + ENT** on the lockbox keypad.
9. The lockbox will display the green **READY** light.
10. Press **FUNC + 3 + ENT** on the lockbox keypad.
11. The lockbox will open the key compartment, allowing access to the battery compartment.
12. After the key compartment opens, remove the power paddle from the lockbox.
13. Slide the **POWER** switch on the power paddle to the **OFF** position.

#### **NXT Wireless Lockbox:**

6. Press and hold the **ENT** button on the lockbox keypad for approximately 2 seconds.
7. Press **FUNC + FUNC + 9 + ENT** on the lockbox keypad.
8. The lockbox will illuminate the **CARD** and **CODE** lights.
9. Wait for the green **Status C** light to illuminate on the power paddle.
10. Enter your **PIN + ENT** into the lockbox keypad.
11. The lockbox will display the green **READY** light.
12. Press **FUNC + 3 + ENT** on the lockbox keypad.
13. The lockbox will open the key compartment, allowing access to the battery compartment.
14. After the key compartment opens, remove the power paddle from the lockbox.
15. Slide the **POWER** switch on the power paddle to the **OFF** position.



#### **Summary**

You can contact Sentrilock Support at 877-736-8745. Support is available 7 days a week, from 8AM to Midnight, EST. Sentrilock Support can assist you in using the power paddle and replacing the lockbox batteries.