

CBS CODES



Call Before Showing Code

Agents:

To obtain your CBS Code

1. Log on to www.sentrilock.com
2. Click on “*Default Lockbox Settings*” on the left hand side
3. Your CBS code will be displayed under “*Call Before Showing*” Settings
4. Give this code to any affiliate you would like to have access to your lockboxes
5. This code does not change, but can be changed. Please call Sentrilock Support for more details

Affiliates:

To Use a CBS Code :

1. Insert your SentiCard into the lockbox with the gold chip facing up
2. Wait for the lockbox to light up, display card, then code
3. Insert your 4 digit PIN number then press enter
4. Once you receive the green ready light, pull your SentiCard out of the lockbox
5. The Lockbox will now ask for the owners CBS code by displaying the “code” light
6. Enter the CBS code followed by enter (which was obtained from the lockbox owner)

If you have any questions please call
Sentrilock Support 1-877-736-8745